

POST-INSTALLATION MAINTENANCE

Karelias nature oil finished floors should be given a supplementary surface treatment with Kährs Satin Oil. The main reason for this is to prevent water penetrating the joints between boards through capillary action.

For further instructions, see section Oil Surface Reconditioning.

Note! UV radiation from the sun alters wood colour over time. Variations in colour – such as carpet outlines – will even out in time as they are exposed to daylight.

MAINTENANCE AND CLEANING

Place suitable mats on both sides of the front door and beneath the coat rack to prevent sand and water from getting into the rooms. Remove abrasive dirt immediately. Protect the floor by applying felt pads under furniture legs etc. When moving furniture such as refrigerators or freezers, cover the floor with, for instance, mats in order to prevent scratches and dents. Office chairs equipped with casters require a mat or a plastic plate designed for the purpose underneath in order to prevent abrasion damage to your wooden floor.

Use as little water as possible when cleaning (almost dry wipe). If visible moisture does not evaporate within a minute, you are using too much water. Immediately wipe away spilled water from the floor. Remove stains when they are fresh, either with water or a mild cleaner and dry the floor. Avoid scrubbing with hard cleaning implements. For daily maintenance, it is enough to vacuum the floor or wipe it with an almost dry mop. Thus the floor surface will dry immediately without visible drop stains appearing. Spills and ingrained dirt is removed using a mop and Kährs Cleaner or Kährs Spray Cleaner. Follow the instruction on the packages, too large amount of concentrate may cause the floor to get dirty more quickly as concentrate layers gather on top of one another.

STAIN REMOVAL

STAIN	REMOVE WITH
Asphalt, rubber, oil, shoe polish, soot	Surgical spirit, petroleum ether or
and dried residues of chocolate or	similar.
grease.	
Crayons, lipstick, felt tip pens.	Surgical spirit.
Candle wax, chewing gum.	Freeze-spray or put a plastic bag of ice cubes on the mark. Then scrape off carefully.
Blood.	Cold water.

OIL SURFACE RECONDITIONING

How often the floor needs maintaining with oil depends on use, cleaning, exposure to sun light

etc. In private areas, this is needed approximately once a year.

- 1. Vacuum clean the floor carefully.
- 2. Clean the floor using Kährs Cleaner and micro mop. Follow the Kährs Cleaner instructions. Only damp cleaning, the surface should be dry again within a minute. For very dirty floors replace the micro mop using a rough brush.
- 3. Remove cleaner and dirt using a wrung out cloth.
- Dry the surface using a dry cloth and leave the floor to dry for 30 minutes. For very dirty floors or on floors with heavy textures, it might be necessary to repeat step 2–4.

5. Apply a thin layer of Kährs Satin Oil on the surface and spread it evenly with a Kährs micro mop or a dry cloth by scrubbing along the texture. Polish again with a new micro mop after 10–15 minutes so that no sticky parts are left. Please observe that two layers of thin oil gives a better result than one thick layer. Applying a too high amount of oil will result in a sticky surface.

RECOMMENDED DOSAGE

After Installation: 100 ml of Kährs Satin Oil per 20 m² – 30 m² Reconditioning: 100 ml of Kährs Satin Oil per 30 m²

DAMAGE REPAIR OF OILED SURFACE

Use the Kährs Woodfiller and Kährs Touch Up for the reconditioning of minor scratches and dents.

MORE SEVERE DAMAGES

If the floor is heavily worn, or needs renovation for some other reason, it can be machine sanded to bare wood and have a new surface treatment applied. For a new oiled surface, please contact your local dealer.

Maintenance of hardwood floors in public places is different from that of floors in private houses. Please contact us for more information.

Visit our website at www.kareliaparketti.com.